

X-MOUNT CAMERA LIST

Make	Model	Global Mount	Global Ring Coupler	Additional Adapter(s)
Canon	EOS 10D	M 528XSLR	M 528XSLR-EOS	
Canon	EOS 1D	M 528XSLR	M 528XSLR-EOS	
Canon	EOS 1D Mark II	M 528XSLR	M 528XSLR-EOS	
Canon	EOS 1Ds	M 528XSLR	M 528XSLR-EOS	
Canon	EOS 20D	M 528XSLR	M 528XSLR-EOS	
Canon	EOS D30	M 528XSLR	M 528XSLR-EOS	
Canon	EOS D300 Rebel	M 528XSLR	M 528XSLR-EOS	
Canon	EOS D60	M 528XSLR	M 528XSLR-EOS	
Canon	PowerShot A10	M 528X	M 528X-SPC	BOW4137T
Canon	PowerShot A20	M 528X	M 528X-SPC	BOW4137T
Canon	PowerShot G1	M 528X	M 528X-SPC	BOW45637T
Canon	PowerShot G2	M 528X	M 528X-SPC	BOW45637T
Canon	PowerShot G3	M 528X	M 528X-SPC	Canon LA-DC58B, Step Down R
Canon	PowerShot G5	M 528X	M 528X-SPC	Canon LA-DC58B, Step Down R
Fuji	S1 Pro	M 528XSLR	M 528XSLR-F	
Fuji	S2 Pro	M 528XSLR	M 528XSLR-F	
Kodak	DCS 315	M 528XSLR	M 528XSLR-F	
Kodak	DCS 620	M 528XSLR	M 528XSLR-F	
Kodak	DCS 620x	M 528XSLR	M 528XSLR-F	
Kodak	DCS 720x	M 528XSLR	M 528XSLR-F	
Kodak	DCS 760	M 528XSLR	M 528XSLR-F	
Kodak	DCS Pro 14n	M 528XSLR	M 528XSLR-F	
Kodak	DCS Pro SLR/n	M 528XSLR	M 528XSLR-F	
Minolta	Diamge 7i	M 528X	M 528X-SPC	Step Down Ring 43mm-37mm & Nikon UR-E4
Nikon	Coolpix 4300	M 528X	M 528X-N	Nikon UR-E4
Nikon	Coolpix 4500	M 528X	M 528X-N	
Nikon	Coolpix 5000	M 528X	M 528X-N	Nikon UR-E6
Nikon	Coolpix 5400	M 528X	M 528X-N5400	
Nikon	Coolpix 775	M 528X	M 528X-N	Nikon UR-E3
Nikon	Coolpix 800	M 528X	M 528X-N	
Nikon	Coolpix 880	M 528X	M 528X-N	Nikon UR-E2
Nikon	Coolpix 885	M 528X	M 528X-N	Nikon UR-E4
Nikon	Coolpix 900	M 528X	M 528X-N	
Nikon	Coolpix 950	M 528X	M 528X-N	
Nikon	Coolpix 990	M 528X	M 528X-N	
Nikon	Coolpix 995	M 528X	M 528X-N	
Nikon	D1	M 528XSLR	M 528XSLR-F	
Nikon	D100	M 528XSLR	M 528XSLR-F	
Nikon	D1H	M 528XSLR	M 528XSLR-F	
Nikon	D1X	M 528XSLR	M 528XSLR-F	
Nikon	D2H	M 528XSLR	M 528XSLR-F	
Nikon	D70	M 528XSLR	M 528XSLR-F	
Olympus	C-2000Z	M 528X	M 528X-SPC	BOW4137T
Olympus	C-2020Z	M 528X	M 528X-SPC	BOW4137T
Olympus	C-2040Z	M 528X	M 528X-SPC	BOW4137T
Olympus	C-3000Z	M 528X	M 528X-SPC	BOW4137T
Olympus	C-3020Z	M 528X	M 528X-SPC	BOW4137T
Olympus	C-3030Z	M 528X	M 528X-SPC	BOW4137T
Olympus	C-3040Z	M 528X	M 528X-SPC	BOW4137T
Olympus	C-4000Z	M 528X	M 528X-SPC	BOW4137T
Olympus	C-4040Z	M 528X	M 528X-SPC	BOW4137T

Olympus	C-5050Z	M 528X	M 528X-SPC	BOW4137T
Olympus	C-700UZ	M 528X	M 528X-SPC	BOW45637T
Olympus	C-720UZ	M 528X	M 528X-SPC	BOW45637T
Olympus	C-730UZ	M 528X	M 528X-SPC	BOW45637T
Olympus	C-740UZ	M 528X	M 528X-SPC	BOW45637T
Olympus	C-750UZ	M 528X	M 528X-SPC	BOW45637T
Pentax	*istD	M 528XSLR	M 528XSLR-USM	
Sony	CCD-TR416	M 528X	M 528X-SPC	
Sony	CCD-TR514	M 528X	M 528X-SPC	
Sony	CCD-TR516	M 528X	M 528X-SPC	
Sony	CCD-TR54	M 528X	M 528X-SPC	
Sony	CCD-TR64	M 528X	M 528X-SPC	
Sony	CCD-TR66	M 528X	M 528X-SPC	
Sony	CCD-TR67	M 528X	M 528X-SPC	
Sony	CCD-TR714	M 528X	M 528X-SPC	
Sony	CCD-TR716	M 528X	M 528X-SPC	
Sony	CCD-TR74	M 528X	M 528X-SPC	
Sony	CCD-TR76	M 528X	M 528X-SPC	
Sony	CCD-TR78	M 528X	M 528X-SPC	
Sony	CCD-TR814	M 528X	M 528X-SPC	
Sony	CCD-TR818	M 528X	M 528X-SPC	
Sony	CCD-TR84	M 528X	M 528X-SPC	
Sony	CCD-TR86	M 528X	M 528X-SPC	
Sony	CCD-TR87	M 528X	M 528X-SPC	
Sony	CCD-TR88	M 528X	M 528X-SPC	
Sony	CCD-TR910	M 528X	M 528X-SPC	
Sony	CCD-TR917	M 528X	M 528X-SPC	
Sony	CCD-TR930	M 528X	M 528X-SPC	
Sony	CCD-TR94	M 528X	M 528X-SPC	
Sony	CCD-TR940	M 528X	M 528X-SPC	
Sony	CCD-TR98	M 528X	M 528X-SPC	
Sony	CCD-TR99	M 528X	M 528X-SPC	
Sony	CCD-TRV108	M 528X	M 528X-SPC	
Sony	CCD-TRV11	M 528X	M 528X-SPC	
Sony	CCD-TRV112	M 528X	M 528X-SPC	
Sony	CCD-TRV118	M 528X	M 528X-SPC	
Sony	CCD-TRV119	M 528X	M 528X-SPC	
Sony	CCD-TRV12	M 528X	M 528X-SPC	
Sony	CCD-TRV128	M 528X	M 528X-SPC	
Sony	CCD-TRV15	M 528X	M 528X-SPC	
Sony	CCD-TRV19	M 528X	M 528X-SPC	
Sony	CCD-TRV21	M 528X	M 528X-SPC	
Sony	CCD-TRV211	M 528X	M 528X-SPC	
Sony	CCD-TRV212	M 528X	M 528X-SPC	
Sony	CCD-TRV215	M 528X	M 528X-SPC	
Sony	CCD-TRV22	M 528X	M 528X-SPC	
Sony	CCD-TRV25	M 528X	M 528X-SPC	
Sony	CCD-TRV29	M 528X	M 528X-SPC	
Sony	CCD-TRV30	M 528X	M 528X-SPC	
Sony	CCD-TRV308	M 528X	M 528X-SPC	
Sony	CCD-TRV312	M 528X	M 528X-SPC	
Sony	CCD-TRV318	M 528X	M 528X-SPC	
Sony	CCD-TRV32	M 528X	M 528X-SPC	

Sony	CCD-TRV328	M 528X	M 528X-SPC	
Sony	CCD-TRV33	M 528X	M 528X-SPC	
Sony	CCD-TRV36	M 528X	M 528X-SPC	
Sony	CCD-TRV40	M 528X	M 528X-SPC	
Sony	CCD-TRV41	M 528X	M 528X-SPC	
Sony	CCD-TRV43	M 528X	M 528X-SPC	
Sony	CCD-TRV46	M 528X	M 528X-SPC	
Sony	CCD-TRV51	M 528X	M 528X-SPC	
Sony	CCD-TRV512	M 528X	M 528X-SPC	
Sony	CCD-TRV52	M 528X	M 528X-SPC	
Sony	CCD-TRV53	M 528X	M 528X-SPC	
Sony	CCD-TRV57	M 528X	M 528X-SPC	
Sony	CCD-TRV58	M 528X	M 528X-SPC	
Sony	CCD-TRV608	M 528X	M 528X-SPC	
Sony	CCD-TRV615	M 528X	M 528X-SPC	
Sony	CCD-TRV62	M 528X	M 528X-SPC	
Sony	CCD-TRV65	M 528X	M 528X-SPC	
Sony	CCD-TRV66	M 528X	M 528X-SPC	
Sony	CCD-TRV67	M 528X	M 528X-SPC	
Sony	CCD-TRV68	M 528X	M 528X-SPC	
Sony	CCD-TRV715	M 528X	M 528X-SPC	
Sony	CCD-TRV72	M 528X	M 528X-SPC	
Sony	CCD-TRV75	M 528X	M 528X-SPC	
Sony	CCD-TRV81	M 528X	M 528X-SPC	
Sony	CCD-TRV815	M 528X	M 528X-SPC	
Sony	CCD-TRV82	M 528X	M 528X-SPC	
Sony	CCD-TRV85	M 528X	M 528X-SPC	
Sony	CCD-TRV87	M 528X	M 528X-SPC	
Sony	CCD-TRV88	M 528X	M 528X-SPC	
Sony	CCD-TRV91	M 528X	M 528X-SPC	
Sony	CCD-TRV93	M 528X	M 528X-SPC	
Sony	CCD-TRV95	M 528X	M 528X-SPC	
Sony	CCD-TRV98	M 528X	M 528X-SPC	
Sony	CCD-TRV99	M 528X	M 528X-SPC	
Sony	DCR-DVD-200	M 528X	M 528X-SPC	Step Down Ring 30mm-37mm
Sony	DCR-DVD-300	M 528X	M 528X-SPC	Step Down Ring 30mm-37mm
Sony	DCR-HC65	M 528X	M 528X-SPC	Step Down Ring 30mm-37mm
Sony	DCR-HC85	M 528X	M 528X-SPC	
Sony	DCR-IP220	M 528X	M 528X-SPC	
Sony	DCR-PC10	M 528X	M 528X-SPC	
Sony	DCR-PC100	M 528X	M 528X-SPC	
Sony	DCR-PC105	M 528X	M 528X-SPC	Step Down Ring 30mm-37mm
Sony	DCR-PC110	M 528X	M 528X-SPC	
Sony	DCR-PC115	M 528X	M 528X-SPC	
Sony	DCR-PC120BT	M 528X	M 528X-SPC	
Sony	DCR-PC330	M 528X	M 528X-SPC	
Sony	DCR-PC7	M 528X	M 528X-SPC	
Sony	DCR-SC100	M 528X	M 528X-SPC	
Sony	DCR-TR7000	M 528X	M 528X-SPC	
Sony	DCR-TRV110	M 528X	M 528X-SPC	
Sony	DCR-TRV120	M 528X	M 528X-SPC	
Sony	DCR-TRV130	M 528X	M 528X-SPC	
Sony	DCR-TRV140	M 528X	M 528X-SPC	

Sony	DCR-TRV20	M 528X	M 528X-SPC	
Sony	DCR-TRV210	M 528X	M 528X-SPC	
Sony	DCR-TRV22	M 528X	M 528X-SPC	Step Down Ring 30mm-37mm
Sony	DCR-TRV230	M 528X	M 528X-SPC	
Sony	DCR-TRV240	M 528X	M 528X-SPC	
Sony	DCR-TRV250	M 528X	M 528X-SPC	
Sony	DCR-TRV260	M 528X	M 528X-SPC	
Sony	DCR-TRV30	M 528X	M 528X-SPC	
Sony	DCR-TRV310	M 528X	M 528X-SPC	
Sony	DCR-TRV315	M 528X	M 528X-SPC	
Sony	DCR-TRV320	M 528X	M 528X-SPC	
Sony	DCR-TRV33	M 528X	M 528X-SPC	Step Down Ring 30mm-37mm
Sony	DCR-TRV330	M 528X	M 528X-SPC	
Sony	DCR-TRV340	M 528X	M 528X-SPC	
Sony	DCR-TRV350	M 528X	M 528X-SPC	
Sony	DCR-TRV360	M 528X	M 528X-SPC	
Sony	DCR-TRV38	M 528X	M 528X-SPC	Step Down Ring 30mm-37mm
Sony	DCR-TRV460	M 528X	M 528X-SPC	
Sony	DCR-TRV5	M 528X	M 528X-SPC	
Sony	DCR-TRV50	M 528X	M 528X-SPC	
Sony	DCR-TRV510	M 528X	M 528X-SPC	
Sony	DCR-TRV520	M 528X	M 528X-SPC	
Sony	DCR-TRV525	M 528X	M 528X-SPC	
Sony	DCR-TRV530	M 528X	M 528X-SPC	
Sony	DCR-TRV7	M 528X	M 528X-SPC	
Sony	DCR-TRV70	M 528X	M 528X-SPC	
Sony	DCR-TRV720	M 528X	M 528X-SPC	
Sony	DCR-TRV730	M 528X	M 528X-SPC	
Sony	DCR-TRV740	M 528X	M 528X-SPC	
Sony	DCR-TRV80	M 528X	M 528X-SPC	
Sony	DCR-TRV820	M 528X	M 528X-SPC	
Sony	DCR-TRV830	M 528X	M 528X-SPC	
Sony	DCR-TRV840	M 528X	M 528X-SPC	
Sony	DCR-TRV9	M 528X	M 528X-SPC	
Sony	DCR-TRV950	M 528X	M 528X-SPC	
Sony	DSC-P30	M 528X	M 528X-SPC	
Sony	DSC-P50	M 528X	M 528X-SPC	
Sony	DSC-S30	M 528X	M 528X-SPC	
Sony	DSC-S50	M 528X	M 528X-SPC	
Sony	DSC-S70	M 528X	M 528X-SPC	BOW4537T
Sony	DSC-S75	M 528X	M 528X-SPC	BOW4537T
Sony	DSC-S85	M 528X	M 528X-SPC	BOW4537T